

Condato Prime	Width (W)	Depth(D)
<b>Depth reference</b>		
1100	700	1100
	800	1100
	900	1100
	1000	1100
	1100	1100
1200	700	1200
	800	1200
	900	1200
	1000	1200
	1100	1200
1300	700	1300
	800	1300
	900	1300
	1000	1300
	1100	1300
1400	700	1400
	800	1400
	900	1400
	1000	1400
	1100	1400
1500	700	1500
	800	1500
	900	1500
	1000	1500
	1100	1500
1600	700	1600
	800	1600
	900	1600
	1000	1600
	1100	1600

**\*\*Shaft Size calculation**

W shaft = W platform + 370 mm (if door is on A or C side)

W shaft = W Platform + 400 mm (if door is on B side )

D shaft = D Platform + 55 mm (if door is on B side )

D shaft = D Platform + 80 mm (if door is on A and C side)

